Listening Safely

To protect your hearing when using headphones, set the volume to the lowest setting before you begin listening, then adjust it to a comfortable level. Wearing headphones while driving a car or riding a bicycle can create a traffic hazard and could be illegal in some areas.

FCC Statement

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn it off. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

- Moving your radio from the receiver
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using the radio.

RadioShack
A Division of Tandy Corporation
Fort Worth, TX 76102
1A8 Printed in Taiwan

OPTIMUS®

AM/FM/TV-Sound Stereo Receiver

n **Digital Tuning**

n **19-Station Memory**

n **Stereo Headphone Jack**

n **Removable Belt Clip**

Owner's Manual

Cat. No. 12-174

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period. *(continued)*

(continued)

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W,
100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell *3/97*

Caring for Your Radio

To enjoy your radio for a long time:

- Handle it gently.
- Keep it away from dust, moisture, and temperature extremes.
- Clean it with a damp cloth. Do not use harsh chemicals.
- Do not take it apart. If something is wrong with the radio, take it to your local RadioShack store for assistance.

INSTALLING BATTERIES

When **E** flashes, turn off the radio, remove the old batteries, and install new ones within 3 minutes.

2 AA Batteries (Cat. No. 23-552)

Cautions:

- Match the polarity symbols (+ and –) marked inside.
- Always use fresh batteries of the required size. Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

USING THE RADIO

Antenna — connect for the best FM/TV reception

Phone — for connecting stereo headphones with a 1/8-inch plug

Headphone/Speaker — slide to to use the headphones, and to to use the speaker.

MEMORY/SELECT — see “Storing Stations”

Belt Clip on the back of the radio —To install, place clip in grooves and slide toward the top of the radio.To remove, press **PUSH** and slide clip down.

VOLUME — rotate to adjust the volume (see “Listening Safely”)

POWER — press to turn the radio on and off. To save batteries, the radio automatically turns off after 60 minutes.

TUNING — press s or t t o select your favorite station; press for 1 second to scan stations

BAND — press to select AM, FM, or TV

MONO (monaural) — press when using headphones to improve the sound of weak FM stations

Lock — slide up to to lock all controls except **VOLUME** and the switch

© 1998 Tandy Corporation.
All Rights Reserved.
Optimus and RadioShack are registered trademarks used by Tandy Corporation.

STORING STATIONS

1. Tune to the desired station.
2. Press **MEMORY.**
3. While **M** flashes, repeatedly press **SELECT** to choose a memory location.
4. Press **MEMORY** again.

To tune stored stations, repeatedly press **SELECT.** To scan stored stations, press for 1 second.

SPECIFICATIONS

AM ..... 530–1710 kHz
FM ..... 88–108 MHz
VHF ..... 2–13 Ch
Output Source ..... 60 mW (10% THD)
Dimensions ..... $4^3/_8 \times 2^5/_8 \times {}^3/_4$ in
Weight (with batteries) ..... 3.7 oz

Specifications are typical; individual units might vary. Specifications are subject to change without notice.